
TAKE-UP (FOR LIVE ROLLERS) 124

SPECIFY MODEL NUMBER PER EXAMPLE

ATSL4-21-R-300 ATSL(pulley diameter)-(between frames)-

(live roller type)-(effective belt pull*) *Specify effective belt pull of conveyor take-up will be





Spring loaded auxiliary take-ups are commonly used on models 138VP, 196VP, 138LR, 196LR, 196CALR, 196ZPA and 251CALR for additional belt take-up.

SPECIFICATIONS

PULLEY: (2) 4" dia. with 1-3/16" dia.

shaft, crowned.

FRAME: 7" x 1-1/2" x 12 ga. steel.

TAKE-UP: 24" belt take-up.

BEARINGS: Heavy duty, relubable, ball bearings with cast iron housings.

MODEL ATSL4 FOR LIVE ROLLERS

BF	15"	19"	21"	25"	27"	33"	39"
WT.	116	125	129	138	142	154	166

■ 3 week shipment

SPRING LOADED AUXILIARY

TAKE-UP (FOR BELT CONVEYORS)

Spring loaded auxiliary take-ups are commonly used on models 250TB, 350SB, 350BSB, 350BOS, 196RB, 196RBF, 350ŚBF and 251RB for additional belt take-up.

SPECIFY MODEL NUMBER PER EXAMPLE

ATSL4-21-B-290

ATSL(pulley diameter)-(between frames)-(belt conveyor type*)-(effective belt pull**)

*When attaching to 250TB or 350BOS, BF dimension = belt width + 1".

**Specify effective belt pull of conveyor take-up will be mounted on.

SPECIFICATIONS

PULLEY: (2) 4" dia. with 1-3/16" dia.

shaft, crowned.

FRAME: 7" x 1-1/2" x 12 ga. steel.

TAKE-UP: 24" belt take-up.

BEARINGS: Heavy duty, relubable, ball bearings with cast iron housings.



MODEL ATSL4 FOR BELT CONV.

9" 15" 21" 27" 33" 39" 45" 51" WT. 132 145 158 171 183 195 207 220

NOTE: Use belt width when ordering for 250TB & 350BOS (belt width + 1" = BF dimension).